SECTION 096513 - RESILIENT BASE AND ACCESSORIES

PART 1 - GENERAL

1.1 SUMMARY

A. Section Includes:

1. Resilient base.
2. Resilient stair accessories.
3. Resilient molding accessories.

1.2 SUBMITTALS

A. Product Data: For each type of product indicated.

B. LEED Submittals:

1. Product Data for Credit EQ 4.1: For adhesives, including printed statement of VOC content and chemical components.

C. Samples: For each type of product indicated, in manufacturer's standard-size Samples but not less than 12 inches (300 mm) long, of each resilient product color, texture, and pattern required.

1.3 QUALITY ASSURANCE

A. Fire-Test-Response Characteristics: As determined by testing identical products according to ASTM E 648 or NFPA 253 by a qualified testing agency.

1. Critical Radiant Flux Classification: Class I, not less than 0.45 W/sq. cm.

1.4 PROJECT CONDITIONS

A. Maintain ambient temperatures within range recommended by manufacturer in spaces to receive resilient products.

B. Until Substantial Completion, maintain ambient temperatures within range recommended by manufacturer.

C. Install resilient products after other finishing operations, including painting, have been completed.

PART 2 - PRODUCTS

2.1 RESILIENT BASE

A. Resilient Base:

1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:

a. Allstate Rubber Corp.; Stoler Industries.
b. Armstrong World Industries, Inc.
c. Burke Mercer Flooring Products; Division of Burke Industries, Inc.
d. Endura Rubber Flooring; Division of Burke Industries, Inc.
e. Estrie Products International; American Biltrite (Canada) Ltd.
f. Flexco, Inc.
g. Johnsonite.
h. Mondo Rubber International, Inc.
i. Musson, R. C. Rubber Co.
j. Nora Rubber Flooring; Freudenberg Building Systems, Inc.
k. PRF USA, Inc.
l. Roppe Corporation, USA.
m. VPI, LLC; Floor Products Division.
n. Or approved equal

B. Resilient Base Standard: ASTM F 1861.

1. Material Requirement: Type TS (rubber, vulcanized thermoset) or Type TP (rubber, thermoplastic).
2. Manufacturing Method: Group I (solid, homogeneous).
3. Style: Cove (base with toe) for resilient flooring; Straight (flat or toeless) for carpet.

C. Minimum Thickness: 0.125 inch (3.2 mm).

D. Height: 4 inches (102 mm).

E. Lengths: Coils in manufacturer's standard length.

F. Outside Corners: Job formed.

G. Inside Corners: Job formed.

H. Finish: Satin.

I. Colors and Patterns: As selected by University from full range of industry colors.

2.2 RESILIENT STAIR ACCESSORIES

A. Resilient Stair Treads:

1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:

   a. Burke Mercer Flooring Products; Division of Burke Industries, Inc.
   b. Endura Rubber Flooring; Division of Burke Industries, Inc.
   c. Estrie Products International; American Biltrite (Canada) Ltd.
   d. Flexco, Inc.
   e. Johnsonite.
   f. Mondo Rubber International, Inc.
   g. Musson, R. C. Rubber Co.
   h. Nora Rubber Flooring; Freudenberg Building Systems, Inc.
   i. PRF USA, Inc.
   j. R.C.A. Rubber Company (The).
   k. Roppe Corporation, USA.
   l. VPI, LLC; Floor Products Division.
   m. Or approved equal

B. Resilient Stair Treads Standard: ASTM F 2169.

1. Material Requirement: Type TS (rubber, vulcanized thermoset) or Type TP (rubber, thermoplastic).
2. Surface Design:
   a. Class 2, Pattern: Raised-rib design.

3. Manufacturing Method: Group 1, tread with embedded abrasive strips.

C. Nosing Style: Square, adjustable to cover angles between 60 and 90 degrees.

D. Nosing Height: 2 inches (51 mm).

E. Thickness: 1/4 inch (6 mm) and tapered to back edge.

F. Size: Lengths and depths to fit each stair tread in one piece or, for treads exceeding maximum lengths manufactured, in equal-length units.

G. Risers: Smooth, flat, toeless, height and length to cover risers; produced by same manufacturer as treads and recommended by manufacturer for installation with treads.

1. Thickness: 0.125 inch (3.2 mm).

H. Stringers: Of same thickness as risers, height and length after cutting to fit risers and treads and to cover stair stringers; produced by same manufacturer as treads and recommended by manufacturer for installation with treads.

I. Colors and Patterns: Match University's sample.

2.3 RESILIENT MOLDING ACCESSORY

A. Resilient Molding Accessory:

1. Manufacturers: Subject to compliance with requirements, provide products by one of the following:

   a. Burke Mercer Flooring Products; Division of Burke Industries, Inc.
   b. Flexco, Inc.
   c. Johnsonite.
   d. R.C.A. Rubber Company (The).
   e. Roppe Corporation, USA.
   f. VPI, LLC; Floor Products Division.
   g. Or approved equal

B. Description: Reducer strip for resilient floor covering.

C. Material: Vinyl.

D. Profile and Dimensions: As indicated.

E. Colors and Patterns: Match University's sample.

2.4 INSTALLATION MATERIALS

A. Trowelable Leveling and Patching Compounds: Latex-modified, portland cement based or blended hydraulic-cement-based formulation provided or approved by manufacturer for applications indicated.

B. Adhesives: Water-resistant type recommended by manufacturer to suit resilient products and substrate conditions indicated.

1. Use adhesives that comply with the following limits for VOC content when calculated according to 40 CFR 59, Subpart D (EPA Method 24):

   a. Cove Base Adhesives: Not more than 50 g/L.
   b. Rubber Floor Adhesives: Not more than 60 g/L.

C. Stair-Tread-Nose Filler: Two-part epoxy compound recommended by resilient tread manufacturer to fill nosing substrates that do not conform to tread contours.

D. Metal Edge Strips: Extruded aluminum with mill finish of width shown, of height required to protect exposed edges of tiles, and in maximum available lengths to minimize running joints.

E. Floor Polish: Provide protective liquid floor polish products as recommended by resilient stair tread manufacturer.

PART 3 - EXECUTION

3.1 PREPARATION

A. Prepare substrates according to manufacturer's written instructions to ensure adhesion of resilient products.

B. Concrete Substrates for Resilient Stair Treads and Accessories: Prepare according to ASTM F 710.

1. Verify that substrates are dry and free of curing compounds, sealers, and hardeners.
2. Remove substrate coatings and other substances that are incompatible with adhesives and that contain soap, wax, oil, or silicone, using mechanical methods recommended by manufacturer. Do not use solvents.
3. Alkalinity and Adhesion Testing: Perform tests recommended by manufacturer.
4. Moisture Testing: Perform tests recommended by manufacturer [**and as follows**]. Proceed with installation only after substrates pass testing.

a. Perform anhydrous calcium chloride test, ASTM F 1869. Proceed with installation only after substrates have maximum moisture-vapor-emission rate of 3 lb of water/1000 sq. ft. (1.36 kg of water/92.9 sq. m) in 24 hours.
b. Perform relative humidity test using in situ probes, ASTM F 2170. Proceed with installation only after substrates have maximum 75 percent relative humidity level measurement.

C. Fill cracks, holes, and depressions in substrates with trowelable leveling and patching compound and remove bumps and ridges to produce a uniform and smooth substrate.

D. Do not install resilient products until they are same temperature as the space where they are to be installed.

1. Move resilient products and installation materials into spaces where they will be installed at least 48 hours in advance of installation.

E. Sweep and vacuum clean substrates to be covered by resilient products immediately before installation.

3.2 RESILIENT BASE INSTALLATION

A. Comply with manufacturer's written instructions for installing resilient base.

B. Apply resilient base to walls, columns, pilasters, casework and cabinets in toe spaces, and other permanent fixtures in rooms and areas where base is required.

C. Install resilient base in lengths as long as practicable without gaps at seams and with tops of adjacent pieces aligned.

D. Tightly adhere resilient base to substrate throughout length of each piece, with base in continuous contact with horizontal and vertical substrates.

E. Do not stretch resilient base during installation.

3.3 RESILIENT ACCESSORY INSTALLATION

A. Comply with manufacturer's written instructions for installing resilient accessories.

B. Resilient Stair Accessories:

1. Use stair-tread-nose filler to fill nosing substrates that do not conform to tread contours.
2. Tightly adhere to substrates throughout length of each piece.
3. For treads installed as separate, equal-length units, install to produce a flush joint between units.

C. Resilient Molding Accessories: Butt to adjacent materials and tightly adhere to substrates throughout length of each piece. Install reducer strips at edges of resilient floor covering that would otherwise be exposed.

3.4 CLEANING AND PROTECTION

A. Comply with manufacturer's written instructions for cleaning and protection of resilient products.

B. Floor Polish: Remove soil, visible adhesive, and surface blemishes from resilient stair treads before applying liquid floor polish.

1. Apply two coat(s).

C. Cover resilient products until Substantial Completion.

END OF SECTION 09 65 13